## 2016 Presidential Debates Frequency Coordination Policy

**IMPORTANT!** The use of any RF equipment\* listed below anywhere on a debate property, at any time, requires prior coordination with the CPD Frequency Coordinator.

Wireless (RF) equipment that must be coordinated prior to use includes, but is not limited to:

Microphones – IFB's – IEM's – Intercom – Cameras STL's – RPU's – PtP Microwave Links – Two-Way Radios

Frequency bands subject to coordination:

54-88MHz, 174-217MHz, 450-451MHz, 455-456MHz, 470-698MHz, 902-928MHz, 944-952MHz, 1435-1525MHz, 2025-2110MHz, 2200-2350MHz, 5850-5915MHz, 6425-6525MHz, 6875-7125MHz.

Submit a completed RF Coordination Request form to the CPD Frequency Coordinator at <a href="mailto:frequencycoord@debates.org">frequencycoord@debates.org</a> as soon as possible.

Failure to follow the directions of the CPD Frequency Coordinator and/or interference to other coordinated users caused by failure to coordinate your wireless devices will result in a request to suspend operation until the device in question can be coordinated or the interference mitigated.

\*WiFi and WLAN equipment operating in the 2.4GHz and/or 5G ISM bands does not require coordination.